

SYNOLAC[®] 92X-55

ARKEMA COATING RESINS

Product Application details SYNOLAC[®] 92X-55 is a short oil oxidising alkyd developed for use in a wide range of vehicle refinishing fast air-drying and stoving applications.

- Performance**
- Rapid drying
 - Excellent color retention
 - Good recoatability
 - Good adhesion on metal substrates

Polymer Type

- Solvent borne Alkyd

Sales Specifications	% Solid Content (at 150°C, 1gm, 1hr,) (ISO 3251)	53 - 57
	Viscosity in Poise at 25°C, Brookfield Viscometer	50 - 60
	Colour, Gardner scale (ISO 4630)	8 Max
	Acid value, mg KOH/g (ISO 2114)	15 Max

Other Characteristics¹	Volatile	Xylene
	Oil Length	28
	Density / Specific Gravity at 20°C, g/ml (ISO 2811)	1.02
	Oil or Fatty Acid Type	Linoleic

Note: Acid value and oil length quoted relative to solid resin

¹ The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications

RECOMMENDATIONS FOR USE

Formulation Guidelines

COMPATIBILITY:

SYNOLAC[®] 92X-55 is partially compatible with some short and medium oil alkyd resins, amino resins. It is incompatible with long oil alkyds, chlorinated rubber, nitrocellulose and vinyl resins.

SOLUBILITY:

SYNOLAC[®] 92X-55 is completely soluble in aromatic hydrocarbons, ketones and esters. It does have very limited solubility in alcohols. It doesn't have solubility in aliphatic hydrocarbons.

DRIERS:

In air drying systems 0.05%CO, 0.5%Pb, 0.1%Ca calculated as metal on solid resins content are recommended.

S.D. - 5 - 10 Min.
T.D. - 45 - 60 Min.
H.D. - O/N

In low bake system recommended temperature is 80 - 90°C and level of Melamine formaldehyde is 5-15% on solid resin.

USES:

SYNOLAC[®] 92X-55 is use for vehicle refinishes, fast drying Industrial finishes and heavy-duty primers.

SYNOLAC[®]
BY ARKEMA

Product Safety

Please refer to the corresponding Safety Data Sheet

Storage & Handling

SYNOLAC[®] 92X-55 should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 30°C. Exposure to direct sunlight should be avoided. Under the above mentioned storage conditions the shelf life of the resin will be 12 months from the date of manufacturing.

September 2016

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

The products described in the document are not Medical grades designated for Medical Device applications. Arkema has implemented an internal Medical Policy regarding the use of Arkema products in Medical Devices applications. Arkema has designated Medical grades to be used for Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications. In addition, except for limited cases as determined by the Medical Device Policy, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. For any use of Arkema's product in Medical Device applications, please contact Arkema's sales network.

**Arkema Chemicals India Pvt Ltd
D43 (1), Trans Thane Creek, MIDC
Industrial Area, Shiravane, Nerul,
Navi Mumbai 400706, India.**

Telephone: +91 22 6737 7100

Fax: +91 22 2768 7998

ARKEMA
INNOVATIVE CHEMISTRY