SYNOCURE® 899 BA 70 LM

PROTECTIVE & MARINE COATINGS

(FORMERLY SYNOCURE® 899 LV 70)

ARKEMA COATING RESINS

Product Application details	SYNOCURE [®] 899 BA 70 LM is a high solids content epoxy acrylic copolymer curing agent designed specifically for use with the Arkema range of SYNOCURE [®] acid and amine functional acrylic resins for the formulation of high quality isocyanate-free 2-component industrial coatings. SYNOCURE [®] 899 BA 70 LM is a lower molecular weight variant of SYNOCURE [®] 899 BA 60. When used in combination with the regular solids acrylics, SYNOCURE [®] 890 S 55 and SYNOCURE [®] 895 S 55, benefits of improved solids and reduced VOC can be achieved.	
Polymer Type	Solventborne Epoxy Acrylic Copolymer	
Sales Specifications	Solid Content at 125°C, % (ISO 3251)	68 - 72
	Viscosity at 25°C, mPa.s (ISO 3219)	450 - 850
	Colour, Hazen scale (ISO 6271)	200 max
Other Characteristics ¹	Volatile	Butyl acetate
	Flash point, °C (ISO 3679)	24
	Density / Specific Gravity at 20°C, g/ml (ISO 2811) Typical weight per epoxide (relative to solid resin)	<u> </u>
	1 The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications	
Formulation Guidelines	<u>RECOMMENDATIONS FOR USE</u> Maximum high solids benefit and low VOC compliance (< 420 g/l) can be achieved when used with the high solids acrylic, SYNOCURE [®] 892 BA 70. This combination produces low VOC, fast drying 2-component isocyanate free coating systems for high durability enamels suitable for heavy duty, maintenance and transport applications.The technical data sheets describing SYNOCURE [®] 890 S 55, SYNOCURE [®] 895 S 55 and SYNOCURE [®] 892 BA 70 give details of the recommended mixing ratios and other formulating considerations. Further information on use may be found in the brochure 'Non-Isocyanate Acrylic resins for 2K Coatings' available from Arkema Coating Resins.SYNOCURE [®] 899 BA 70 LM is designed exclusively for use with the acrylic resins specified and should not be used in other non-isocyanate systems.SYNOCURE [®] 899 BA 70 LM should only be used in applications consistent with the above recommendations. Proposals to use the resin in any other way should be discussed with Arkema before any action is taken.	



Product Safety	Please refer to the corresponding Safety Data Sheet.
Storage &	SYNOCURE [®] 899 BA 70 LM should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 30°C. Exposure to direct sunlight should be avoided.
Handling	In the above mentioned storage conditions the shelf life of the resin will be 6 months from the shipping date

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in medical devices applications that are in contact with the body or circulating bodily fluids (http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html) Arkema has designated medical grades to be used for such medical device applications. Products that have not been designated as medical grades are not authorized by Arkema for use in medical device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in medical device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Arkema Coating Resins

420, rue d'Estienne d'Orves

92705 Colombes Cedex - France arkema.com - arkemacoatingresins.com

