

# SYNOCURE® 9260 BA 70 (FORMERLY E 20600)

GENERAL INDUSTRY

ARKEMA COATING RESINS

## Product

SYNOCURE® 9260 BA 70 is a high solid hydroxy functional acrylic designed to crosslink at room temperature or forced air drying with aliphatic polyisocyanates.

## Application details

SYNOCURE® 9260 BA 70 is particularly recommended for use in vehicle refinishing, and for all high performance industrial applications where high performance is required.

## Performance Benefits

- Fast drying
- Excellent hardness of film
- Excellent chemical resistance

## Polymer Type

- Solventborne Acrylic

## Sales Specifications

Solid Content at 125°C, % (ISO 3251)	69 - 71
Viscosity at 25°C, mPa.s (ISO 3219)	3500 - 5500
Colour, Hazen scale (ISO 6271)	75 max
Acid value, mg KOH/g (ISO 2114)	10 max

## Other Characteristics<sup>1</sup>

Volatile	Butyl acetate
Flash point, °C (ISO 3679)	27
Density / Specific Gravity at 20°C, g/ml (ISO 2811)	1.01
Hydroxyl Content, %	2.9
Hydroxyl Equivalent weight	586

Note: Acid value and/or Hydroxyl value quoted relative to solid resin

<sup>1</sup> The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications

## RECOMMENDATIONS FOR USE

SYNOCURE® 9260 BA 70 should be mixed with the selected polyisocyanate just prior to application. It is preferable to use stoichiometric ratios to obtain optimum performance.

The reaction ratio is calculated from the respective equivalent weight or hydroxyl and isocyanate content of the reactants. The relationship is:

$$\text{Hydroxyl equivalent weight} = \frac{17 \times 100}{\% \text{ OH}}$$

$$\text{Isocyanate equivalent weight} = \frac{42 \times 100}{\% \text{ NCO}}$$

Using Tolonate® HDT-LV2 (1), the recommended ratios would be:

	on solid resin	as supplied
SYNOCURE® 9260 BA 70	586	837
Tolonate® HDT-LV2 (1)	183	183

## Formulation Guidelines

At normal temperatures, the surface drying time of varnishes based upon this combination is around 20 – 30 minutes, when we add 0.10-0.15 % of catalyst (based on solid acrylic resin). The catalyst used is dibutyl tin dilaurate.

Notes: (1) Vencorex Chemicals

SYNOCURE®

---

**Product Safety**

Please refer to the corresponding Safety Data Sheet.

---

**Storage & Handling**

SYNOCURE® 9260 BA 70 should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 30°C. Exposure to direct sunlight should be avoided.

In the above mentioned storage conditions the shelf life of the resin will be 12 months from the shipping date

---

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in medical devices applications that are in contact with the body or circulating bodily fluids (<http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html>) Arkema has designated medical grades to be used for such medical device applications. Products that have not been designated as medical grades are not authorized by Arkema for use in medical device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in medical device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

**Arkema Coating Resins**

420, rue d'Estienne d'Orves

92705 Colombes Cedex - France

arkema.com - [arkemacoatingresins.com](http://arkemacoatingresins.com)

