

SYNOLAC® 267 ND 60

CAN COATINGS

ARKEMA COATING RESINS

Product Application details

SYNOLAC® 267 ND 60 is an acrylic modified polyester resin. SYNOLAC® 267 ND 60 is recommended for "wet-on-wet" overprint varnishes and metal decorating enamels with good standing mechanical processing properties.

Performance Benefits

- Very good mechanical and chemical resistance
- Excellent resistance to sterilization processes
- Good exterior durability, and to the overbaking

Polymer Type

- Solventborne Polyester

Sales Specifications

Solid Content at 135°C, % (ISO 3251)	59 - 61
Viscosity at 25°C, mPa.s (Brookfield SC4-25/13R, 13.2s-1) (ISO 3219)	2000 - 4500
Colour, Gardner scale (ISO 4630)	2 max
Acid value, mg KOH/g (ISO 2114)	12 max

Other Characteristics¹

Volatile	Solvent naphtha 180°C - 200°C low naphthalene content
Flash point, °C (ISO 3679)	64
Density / Specific Gravity at 25°C, g/ml (ISO 2811)	1.07
Hydroxyl Content, %	1.36 - 1.97

Note: Acid value and/or Hydroxyl value quoted relative to solid resin

¹ The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications

Formulation Guidelines

SOLUBILITY

SYNOLAC® 267 ND 60 is soluble in aromatic hydrocarbons, esters, ketones, glycol ethers, methylene chloride, tetraline and 2 nitropropane and has a limited solubility in aliphatic hydrocarbons and alcohols.

COMPATIBILITY

SYNOLAC® 267 ND 60 is compatible with cardura resins, epoxy esters, hexamethoxymethylmelamine, benzoguanamine, nitrocellulose, vinylchloride resins, aldehyde resins, phthalate plasticizers and majority epoxy resins (Epikote™ Resin 1001 (1) partially only), majority reactive melamine resins (Cymel® 370 (2) partially only) and with Neocryl® B-725 (3) (thermoplastic acrylic resin). It is partially compatible with acetobutyrate.

It is incompatible with saturated polyester, urea resins, majority isocyanate resins and with Paraloid™ B-44 (4) (thermoplastic acrylic resin).

Notes: (1) Momentive, (2) Allnex, (3) DSM, (4) Dow

SYNOLAC®

Product Safety

Please refer to the corresponding Safety Data Sheet.

Storage & Handling

SYNOLAC® 267 ND 60 should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 30°C. Exposure to direct sunlight should be avoided.

In the above mentioned storage conditions the shelf life of the resin will be 6 months from the shipping date

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in medical devices applications that are in contact with the body or circulating bodily fluids (<http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html>) Arkema has designated medical grades to be used for such medical device applications. Products that have not been designated as medical grades are not authorized by Arkema for use in medical device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in medical device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Arkema Coating Resins

420, rue d'Estienne d'Orves

92705 Colombes Cedex - France

arkema.com - arkemacoatingresins.com

The logo for ARKEMA, featuring the word "ARKEMA" in a bold, sans-serif font. The letters "A", "R", "K", "E", and "M" are in a dark blue color, while the letter "A" at the end is in a teal color.