

SYNOLAC® 5086

GENERAL INDUSTRY

ARKEMA COATING RESINS

Product Application details

SYNOLAC® 5086 is a low viscosity linear saturated polyester with good compatibility designed for blending with other systems in order to increase solids and reduce volatile organic contents. SYNOLAC® 5086 is a highly versatile resin that can be used in diverse end-uses such as 2-component acrylic isocyanate or polyester isocyanate systems and high quality stoving systems. SYNOLAC® 5086 will react into the blended system via its high hydroxyl content, and will not compromise durability.

Performance Benefits

- Reduce volatile organic content
- Increase solids content
- Improve flexibility and toughness at low temperatures

Polymer Type

- Solventborne Polyester

Sales Specifications

Viscosity at 25°C, mPa.s (ISO 3219)	5500 - 8500
Colour, Hazen scale (ISO 6271)	300 max
Acid value, mg KOH/g (ISO 2114)	7 max

Other Characteristics¹

Density / Specific Gravity at 25°C, g/ml	1.12
Hydroxyl Content, %	5,7 - 6,7
Hydroxyl Value, mg KOH/g	190 - 220
Solid Content, %	100

Note: Acid value and/or Hydroxyl value quoted relative to solid resin

1 The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications

RECOMMENDATIONS FOR USE

It is suggested that initial evaluations be carried out using SYNOLAC® 5086 at a substituted level of 20% of the main binder.

(a) 2-component systems

When used in combination with other hydroxyl containing resins in 2-component systems, SYNOLAC® 5086 will react with aromatic isocyanates such as Desmodur® L series (1) and aliphatic isocyanates such as Tolonate™ HDB series (2) and Desmodur® N series (1).

Formulation Guidelines

Recommended ratios using typical isocyanates would be:

The reaction ratio is calculated from the respective equivalent weight or hydroxyl and isocyanate content of the reactants. The relationship is:

$$\text{Hydroxyl equivalent weight} = \frac{17 \times 100}{\% \text{ OH}}$$

$$\text{Isocyanate equivalent weight} = \frac{42 \times 100}{\% \text{ NCO}}$$

SYNOLAC®

	on solid resin	as supplied
SYNOLAC® 5086	281	281
Desmodur® N 75 series (1)	191	255
Tolonate™ HDB 75 MX (2)	191	255
Desmodur® L 75 (1)	242	323

(b) stoving systems

When used in combination with other resins in stoving systems, SYNOLAC® 5086 will react with most melamine resins, resin solids ratios of between 70:30 and 85:15 binder to amino are suggested.

SOLUBILITY

SYNOLAC® 5086 is completely soluble in aromatic hydrocarbons, esters and ketones and insoluble in aliphatic hydrocarbons.

COMPATIBILITY

SYNOLAC® 5086 is compatible with many resins including polyesters, acrylics, isocyanates, melamine, urea and alkyd resins.

Notes: (1) Bayer MaterialScience, (2) Vencorex Chemicals

Product Safety

Please refer to the corresponding Safety Data Sheet.

Storage & Handling

SYNOLAC® 5086 should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 30°C. Exposure to direct sunlight should be avoided. In the above mentioned storage conditions the shelf life of the resin will be 6 months from the shipping date

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in medical devices applications that are in contact with the body or circulating bodily fluids (<http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html>) Arkema has designated medical grades to be used for such medical device applications. Products that have not been designated as medical grades are not authorized by Arkema for use in medical device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in medical device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Arkema Coating Resins

420, rue d'Estienne d'Orves

92705 Colombes Cedex - France

arkema.com - arkemacoatingresins.com

ARKEMA