

SYNOLAC[®] S53W60

Medium Oil Alkyd

ARKEMA COATING RESINS

Product

Application details

SYNOLAC[®] S53W60 is a medium oil, air drying alkyd intended for industrial paints with good colour retention. It can be used equally well both indoor and outdoor. It is most suitable for use in spraying paints, but can also be easily formulated to suit paints for application by brush.

Performance Benefits

- Fast drying
- Good Gloss
- Good durability

Polymer Type

- Solventborne alkyd

Sales Specifications

Solid Content at 125°C, % (ISO 3251)	59 - 61
Viscosity at 25°C, Gardner Holdt	Z6Z7 – Z7
Colour, Gardner scale (ASTM D1544)	5 max
Acid value, mg KOH/g (ISO 2114)	5 - 8

Other Characteristics¹

Volatile	White Spirit
Density / Specific Gravity at 25°C, g/ml (ISO 2811)	0.95
Type of oil / fatty acid	Soy bean oil
oil / fatty acid content, %	53

Note: Acid value quoted relative to solid resin

¹ The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications

RECOMMENDATIONS FOR USE

SYNOLAC[®] S53W60 is recommended for both industrial and decorative paints, which require good colour retention. It can also be used for road marking paints, in combination with chlorinated rubber.

In air drying applications the recommended driers are 0.05% Cobalt, 0.15% Zirconium, and up to 0.2% Calcium, all expressed as metals on solid resin.

Formulation Guidelines

SOLUBILITY

Aromatic hydrocarbon	Complete
Aliphatic Hydrocarbon	Complete
Alcohol	Partial

COMPATIBILITY

Long Oil Alkyd	Very Good
Linseed Oil	Very Good
Stand Oil	Very Good
Medium Oil Alkyd	Good
Short Oil Alkyd	Fair

SYNOLAC[®]

**Product
Safety**

Please refer to the corresponding Safety Data Sheet.

**Storage &
Handling**

SYNOLAC® S53W60 should be stored indoors in the original, unopened and undamaged container, in a dry place at a temperature not exceeding 35°C. Exposure to direct sunlight should be avoided.

In the above mentioned storage conditions the shelf life of the resin will be 12 months.

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Arkema expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in medical devices applications that are in contact with the body or circulating bodily fluids (<http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html>) Arkema has designated medical grades to be used for such medical device applications. Products that have not been designated as medical grades are not authorized by Arkema for use in medical device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in medical device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Arkema Coating Resins Malaysia Sdn Bhd

PLO 491, Jalan Keluli, Pasir Gudang Industrial Estate,

81700 Pasir Gudang, Johor, Malaysia.

arkema.com - arkemacoatingresins.com

The logo for ARKEMA, featuring the word "ARKEMA" in a bold, sans-serif font. The letters "AR" are in blue, and "KEMA" is in green.